

# CAPABILITIES LIST

Current as of: 11/01/2020

## Limited Airframe

<u>Manufacturer</u>	<u>Model</u>	<u>Part Number</u>
N/A	N/A	N/A

## Limited Radio

<u>Manufacturer</u>	<u>Model</u>	<u>Part Number</u>
Ameri-King	AK-350 Altitude Encoder (Bench Test Only)	AK-350 AK-35035 AK-35040 AK-35050 AK-35060 AK-35080
Bendix/King	KA-39 Voltage Converter	071-01041-0001
Bendix/King	KA-42B ADF Loop/Sense Antenna	071-01133-0000
Bendix/King	KA-120 DME/GS Serial to Parallel Code Converter	069-01089-0000
Bendix/King	KA-134 Audio Panel	071-02009-0002 071-02009-0012
Bendix/King	KAS-297B Altitude/VS Selector	065-00065-0001
Bendix/King	KDI-570 DME Indicator	066-03003-0000
Bendix/King	KDI-571 DME Indicator	066-03032-0000 066-03032-0001 066-03032-0002 066-03032-0003 066-03032-0004 066-03032-0005 066-03032-0006 066-03032-0007 066-03032-0008 066-03032-0009 066-03032-0010 066-03032-0011

# CAPABILITIES LIST

Current as of: 11/01/2020

Bendix/King	KDI-571 DME Indicator (Cont)	066-03032-0012
		066-03032-0013
		066-03032-0014
		066-03032-0015
		066-03032-0016
		066-03032-0017
		066-03032-0018
		066-03032-0019
		066-03032-0020
		066-03032-0021
Bendix/King	KDI-572 DME Indicator	066-01069-0000
		066-01069-0001
Bendix/King	KDI-573 DME Indicator	066-01069-0002
Bendix/King	KDI-574 DME Indicator	066-01069-0004
Bendix/King	KDM-705A DME	066-01037-0000
		066-01037-0001
		066-01037-0002
		066-01037-0003
		066-01037-0006
		066-01037-0007
Bendix/King	KDM-705A DME Receiver/Transmitter	066-01037-0004
		066-01037-0005
		066-01037-0008
		066-01037-0009
Bendix/King	KI-201C VOR/LOC Converter Indicator	066-03008-0002
		066-03008-0003
Bendix/King	KI-202 GPS/VOR/LOC Indicator	066-03034-0007
Bendix/King	KI-203 VOR/LOC Indicator	066-03034-0000
Bendix/King	KI-204 VOR/LOC/GS Indicator	066-03034-0002
		066-03034-0003
		066-03034-0022
Bendix/King	KI-205 VOR/LOC Indicator	066-03039-0000

# CAPABILITIES LIST

Current as of: 11/01/2020

Bendix/King	KI-206 GPS/VOR/LOC/GS Indicator	066-03034-0004 066-03034-0005 066-03034-0012
Bendix/King	KI-207 VOR/LOC/GS Repeater Indicator	066-03034-0006 066-03034-0017 066-03034-0025
Bendix/King	KI-208 VOR/LOC Converter Indicator	066-03056-0000 066-03056-0002
Bendix/King	KI-208A VOR/LOC Converter Indicator	066-03056-0010
Bendix/King	KI-209 VOR/LOC/GS Indicator	066-03056-0001 066-03056-0003
Bendix/King	KI-209A VOR/LOC/GS Indicator	066-03056-0011
Bendix/King	KI-211C VOR/LOC/GS Indicator/Receiver	069-01010-0004
Bendix/King	KI-212 NAV Indicator	069-01010-0003
Bendix/King	KI-213 NAV Indicator	066-03025-0000
Bendix/King	KI-214 VOR/LOC/GS Indicator/Receiver	066-03025-0001 066-03025-0002 066-03025-0007
Bendix/King	KI-227 ADF Indicator	066-03063-0000 066-03063-0001
Bendix/King	KI-266 DME Indicator	066-03047-0000
Bendix/King	KI-267 DME Indicator	066-03052-0000
Bendix/King	KLN-89B IFR-Approach GPS / Moving Map	066-01148-0101 066-01148-0102
Bendix/King	KLN-94 GPS Navigation System	069-01034-0101 069-01034-0102
Bendix/King	KLX-135A VFR GPS/Moving Map/Comm Transceiver	069-01029-0703

# CAPABILITIES LIST

Current as of: 11/01/2020

Bendix/King	KMA-20 Marker Beacon Receiver	066-01024-0000 066-01024-0001 066-01024-0002 066-01024-0003 066-01024-0004 066-01024-0005 066-01024-0006 066-01024-0007 066-01024-0008 066-01024-0009 066-01024-0010 066-01024-0011 066-01024-0012 066-01024-0013 066-01024-0014 066-01024-0015 066-01024-0016
Bendix/King	KMA-24 Audio Panel Marker Beacon Receiver	066-01055-0000 066-01055-0001 066-01055-0002 066-01055-0003
Bendix/King	KMA-24H Audio Panel/Intercom	066-01055-0050 066-01055-0051 066-01055-0052 066-01055-0053 066-01055-0070 066-01055-0071
Bendix/King	KMA-26 Audio Amplifier/Intercom/Mkr Bcn Rec	066-01155-0101 066-01155-0201
Bendix/King	KN-53 VHF Navigation Receiver	066-01067-0001 066-01067-0005
Bendix/King	KN-62 DME	064-01064-0000
Bendix/King	KN-62A DME	064-01068-0000 064-01068-0001
Bendix/King	KN-63 DME	066-01070-0000 066-01070-0001

# CAPABILITIES LIST

Current as of: 11/01/2020

Bendix/King	KN-64 DME	064-01088-0000
Bendix/King	KN-65A DME	066-01029-0002 066-01029-0003
Bendix/King	KN-72 VOR /LOC Converter	066-04099-0000
Bendix/King	KN-75 Remote GS Receiver	066-01063-0000
Bendix/King	KNR-630 NAV / GS / Manual VOR / RMI	066-04007-0000
Bendix/King	KNR-631 NAV / GS / RMI	066-04007-0001
Bendix/King	KNR-632 NAV / Manual VOR / RMI	066-04007-0002
Bendix/King	KNR-633 RMI	066-04007-0003
Bendix/King	KNS-80 NAV / RNAV / DME / Glideslope Receiver	066-04008-0000
Bendix/King	KNS-81 NAV / RNAV / Glideslope Receiver	066-04020-0000 066-04020-0010
Bendix/King	KR-86 ADF Receiver	066-01038-0000
Bendix/King	KR-87 ADF Receiver	066-01072-0000 066-01072-0001 066-01072-0002 066-01072-0003 066-01072-0004 066-01072-0005 066-01072-0006 066-01072-0007 066-01072-0014 066-01072-0015 066-01072-0017
Bendix/King	KS-178 Primary Servo	065-00051-0001
Bendix/King	KT-71 Transponder	066-01141-5101 066-01141-5201 066-01141-6101
Bendix/King	KT-76 Transponder	066-01034-0000 066-01034-0001

# CAPABILITIES LIST

Current as of: 11/01/2020

Bendix/King	KT-76A Transponder	066-01062-0000 066-01062-0002 066-01062-0010
Bendix/King	KT-76C Transponder	066-01156-0101 066-01156-0201
Bendix/King	KT-78 Transponder	066-01034-0002 066-01034-0003
Bendix/King	KT-78A Transponder	066-01062-0001
Bendix/King	KT-79 Transponder	066-01053-0000 066-01053-0001 066-01053-0002 066-01053-0003
Bendix/King	KX-99 Handheld NAV/COMM	069-01026-0000
Bendix/King	KX-125 NAV/COMM/Indicator	069-01028-0101 069-01028-0201 069-01028-1101
Bendix/King	KX-145 NAV/COMM Transceiver	069-01022-0000
Bendix/King	KX-155 NAV/COMM Transceiver	069-01024-0000 069-01024-0001 069-01024-0002 069-01024-0003 069-01024-0004 069-01024-0005 069-01024-0006 069-01024-0007 069-01024-0008 069-01024-0009 069-01024-0010 069-01024-0011 069-01024-0012 069-01024-0013 069-01024-0020 069-01024-0030 069-01024-0031 069-01024-0032

# CAPABILITIES LIST

Current as of: 11/01/2020

Bendix/King	KX-155 NAV/COMM Transceiver (cont)	069-01024-0033 069-01024-0034 069-01024-0035 069-01024-0036 069-01024-0037 069-01024-0038 069-01024-0039 069-01024-0040 069-01024-0041 069-01024-0042 069-01024-0043
Bendix/King	KX-155A NAV/COMM Transceiver	069-01032-0101 069-01032-0201
Bendix/King	KX-165 NAV/COMM Transceiver	069-01025-0000 069-01025-0001 069-01025-0002 069-01025-0003 069-01025-0004 069-01025-0005 069-01025-0006 069-01025-0007 069-01025-0020 069-01025-0021 069-01025-0022 069-01025-0023 069-01025-0024 069-01025-0025 069-01025-0026 069-01025-0027
Bendix/King	KX-165A NAV/COMM Transceiver	069-01033-0101 069-01033-0201
Bendix/King	KX-170A NAV/COMM Transceiver	069-01017-0000
Bendix/King	KX-170B NAV/COMM Transceiver	069-01020-0000
Bendix/King	KX-170BE NAV/COMM Transceiver	069-01020-0001
Bendix/King	KX-175 NAV/COMM Transceiver	069-01016-0000
Bendix/King	KX-175B NAV/COMM Transceiver	069-01019-0000

# CAPABILITIES LIST

Current as of: 11/01/2020

Bendix/King	KX-175BE NAV/COMM Transceiver	069-01019-0001
Bendix/King	KXP-755 Transponder	066-01041-0000
Bendix/King	KXP-7500 Transponder	066-01056-0000 066-01056-0001
Bendix/King	KY-96A VHF COMM Transceiver	064-01052-0010 064-01052-0011 064-01052-0030 064-01052-0031
Bendix/King	KY-96A VHF COMM Transceiver	064-01052-0050 064-01052-0051 064-01052-0060 064-01052-0061 064-01052-0070
Bendix/King	KY-97A VHF COMM Transceiver	064-01051-0010 064-01051-0011 064-01051-0030 064-01051-0031 064-01051-0050 064-01051-0051 064-01051-0060 064-01051-0061 064-01051-0070
Bendix/King	KY-195 COMM Transceiver	069-01018-0000
Bendix/King	KY-195B COMM Transceiver	069-01021-0000
Bendix/King	KY-195BE COMM Transceiver	069-01021-0001
Bendix/King	KY-196 COMM Transceiver	064-01019-0000 064-01019-0001 064-01019-0005 064-01019-0010 064-01019-0020
Bendix/King	KY-196E COMM Transceiver	064-01019-0001



# CAPABILITIES LIST

Current as of: 11/01/2020

Bendix/King	KY-197 COMM Transceiver	064-01021-0000 064-01021-0001 064-01021-0005 064-01021-0010 064-01021-0020
Bendix/King	KY-197E COMM Transceiver	064-01021-0001 064-01021-0011
Cessna/ARC	ASP-310 Audio Select Panel	ASP-310
Cessna/ARC	ASP-310A Audio Select Panel	ASP-310A
Cessna/ARC	C-476A DME Control Unit	44020-1000
Cessna/ARC	C-876A DME Control Unit	46110-0000
Cessna/ARC	C-1038A Control Unit	45670-0000
Cessna/ARC	C-1048A Nav Control Unit	45720-0000
Cessna/ARC	CA-295B Autopilot Controller	43610-1000 43610-1201 43610-1202
Cessna/ARC	DV-1060A Power Inverter (Bench Test Only)	47550-0000
Cessna/ARC	F-1010B Audio Amplifier	49200-0000 49200-0001
Cessna/ARC	IN-346A ADF Indicator	40980-1001
Cessna/ARC	IN-380AC NAV Indicator	50570-1200
Cessna/ARC	IN-385A NAV Indicator	46860-1000
Cessna/ARC	IN-385AC NAV Indicator	46860-1200
Cessna/ARC	IN-386A NAV Indicator	46860-2000
Cessna/ARC	IN-386AC NAV Indicator	46860-2200
Cessna/ARC	IN-485AC NAV Indicator	46870-1300

# CAPABILITIES LIST

Current as of: 11/01/2020

Cessna/ARC	IN-486AC NAV Indicator	46870-2300
Cessna/ARC	IN-514B VOR/LOC Indicator	45010-1000
Cessna/ARC	IN-514R VOR/LOC Indicator	31640-0001
Cessna/ARC	IN-525B VOR/LOC/Glideslope Indicator	45010-2000
Cessna/ARC	IN-1049AC Course Indicator	46880-2310
Cessna/ARC	LSE Audio Panel	LSE
Cessna/ARC	PA-495A-2 Actuator	45850-2909
Cessna/ARC	PA-495A-3 Actuator	53100-0091
Cessna/ARC	PA-510A Actuator 14V	26360-0000 26360-0100
Cessna/ARC	PA-511A Actuator 28V	29510-0000 29510-0001
Cessna/ARC	R-402A Marker Beacon	42410-5114 42410-5128
Cessna/ARC	R-443B Glide Slope Receiver	42100-0000
Cessna/ARC	R-446A ADF Receiver	43090-1028 43090-1128
Cessna/ARC	R-546A ADF Receiver	41240-1001 41240-0111 41240-1000 41240-0000
Cessna/ARC	R-546E ADF Receiver	41240-0101 41240-0100 41240-0001
Cessna/ARC	R-1043A Glide Slope Receiver	45980-0000
Cessna/ARC	R-1048A Nav Receiver	45700-0001

# CAPABILITIES LIST

Current as of: 11/01/2020

Cessna/ARC	R-1048B Nav Receiver	45700-0002
Cessna/ARC	RN-878A Area Navigation	46030-1000
Cessna/ARC	RT-328D NAV/COMM Transceiver	43340-1014 43340-1114
Cessna/ARC	RT-328T NAV/COMM Transceiver	43340-1024 43340-1124
Cessna/ARC	RT-359A Transponder	41420-0014 41420-0028 41420-1114 41420-1128
Cessna/ARC	RT-385A S/N: 39,999 and Below	46660-1000 46660-1100
Cessna/ARC	RT-385A S/N: 40,000 and Above	46660-1000 46660-1100
Cessna/ARC	RT-428A NAV/COMM	43330-1028 43330-1128 43330-0028 43330-1038 43330-1138 43330-0038
Cessna/ARC	RT-459A Transponder	41470-0014 41470-0028 41470-1114 41470-1128 41470-1014 41470-1028
Cessna/ARC	RT-485A NAV/COMM	47360-1000 47360-1100
Cessna/ARC	RT-485B NAV/COMM	49250-1000
Cessna/ARC	RT-859A Transponder	42260-0028 42260-1028
Cessna/ARC	RT-1038A VHF Comm Transceiver	45600-0000

# CAPABILITIES LIST

Current as of: 11/01/2020

Cessna/ARC	RTA-476A DME	44000-0000
Cessna/ARC	RTA-876A DME	46100-0000
Cessna/ARC	RTA-477A DME	50950-0000 50930-0000
Cessna/ARC	RTA-1077B DME	49150-2000 49600-2000
Cessna/ARC	SE Audio Panel	SE
Cessna/ARC	SP-105B-1 Synchrophaser	43380-0002
Collins	ANS-351 Area Navigation Computer	622-3767-001 622-3767-002 622-3767-003 622-3767-004 622-3767-005 622-3767-006
Collins	ANS-351C Area Navigation Computer	622-5579-001
Collins	DME-40 DME Transceiver	622-1233-001
Collins	GLS-350 Glideslope Receiver	622-2084-001
Collins	GLS-350E Glideslope Receiver	622-3366-001
Collins	IND-350 NAV Indicator	622-2082-001 622-2082-002 622-2082-003
Collins	IND-350A NAV Indicator	622-4477-001
Collins	IND-351 NAV Indicator	622-2083-001 622-2083-002 622-2083-003
Collins	IND-351A NAV Indicator	622-4478-001
Collins	IND-351C NAV Indicator	622-2425-001 622-2425-002
Collins	IND-351D NAV Indicator	622-4479-001

# CAPABILITIES LIST

Current as of: 11/01/2020

Collins	IND-450C DME Indicator	622-5588-001
Collins	IND-650A ADF Indicator	690113-P
Collins	RCR-650A	690108-P
Collins	TCR-451 DME Transceiver	622-3670-001
Collins	TDR-90 Transponder	622-1270-001
Collins	TDR-950 Transponder	622-2092-001 622-2092-002 622-2092-003 622-2092-004 622-2092-005 622-2092-006
Collins	TDR-950L Transponder	622-3004-001 622-3004-002 622-3004-003
Collins	TDR-950L Transponder	622-3004-004 622-3004-005 622-3004-006
Collins	VHF-250 COMM Transceiver	622-2079-001 622-2079-002
Collins	VHF-250S COMM Transceiver	622-3364-001
Collins	VHF-250E COMM Transceiver	622-3365-001
Collins	VHF-251 COMM Receiver	622-2078-001
Collins	VHF-251A COMM Receiver	01181-1
Collins	VHF-253 COMM Transceiver	622-5640-001
Collins	VIR-350 NAV Receiver	622-2081-001
Collins	VIR-351 NAV Receiver	622-2080-001 622-2080-011

# CAPABILITIES LIST

Current as of: 11/01/2020

Edo-Aire	RT-553	112001 112002
Edo-Aire	RT-553A	121201 121202
Edo-Aire	RT-563 NAV / COMM, Receiver/Transmitter	123401
Edo-Aire	RT-563A NAV/COMM	123402
Garmin	GMA-340 Audio Panel	011-00401-00 011-00401-01 011-00401-10 011-00401-20
Garmin	GNC-420 GPS / COMM (Battery Replacement, Alignment, Calibration, and Testing)	010-00173-11
Garmin	GNC-420A GPS / COMM (Battery Replacement, Alignment, Calibration, and Testing)	011-00837-00 011-00837-10
Garmin	GNC-420W GPS / COMM (Battery Replacement, Alignment, Calibration, and Testing)	011-01058-00 011-01058-10 011-01058-40 011-01058-45 011-01058-50
Garmin	GNC-420AW GPS / COMM (Battery Replacement, Alignment, Calibration, and Testing)	011-01059-00 011-01059-10 011-01059-40 011-01059-50
Garmin	GNS-430 GPS / NAV / COMM (Battery Replacement, Alignment, Calibration, and Testing)	011-00280-00 011-00280-10 011-00280-30
Garmin	GNS-430A GPS / NAV / COMM (Battery Replacement, Alignment, Calibration, and Testing)	011-00836-00 011-00836-10
Garmin	GNS-430W GPS / NAV / COMM (Battery Replacement, Alignment, Calibration, and Testing)	011-01060-00 011-01060-10 011-01060-40 011-01060-45 011-01060-50

# CAPABILITIES LIST

Current as of: 11/01/2020

Garmin	GNS-430AW GPS / NAV / COMM (Battery Replacement, Alignment, Calibration, and Testing)	011-01061-00
		011-01061-10
		011-01061-40
		011-01061-50
Garmin	GNS-530 Series GPS / NAV / COMM (Battery Replacement, Alignment, Calibration, and Testing)	011-00550-10
Garmin	GPS-155 GPS / Receiver (Battery Replacement, Alignment, Calibration, and Testing)	011-00104-00
Garmin	GPS-400 GPS (Battery Replacement, Alignment, Calibration, and Testing)	011-00504-00
		011-00504-10
Garmin	GPS-400W GPS (Battery Replacement, Alignment, Calibration, and Testing)	011-01057-00
		011-01057-10
		011-01057-40
		011-01057-50
Garmin	GPS-420 GPS / COMM (Battery Replacement, Alignment, Calibration, and Testing)	011-00506-00
		011-00506-10
		011-00506-30
Garmin	GTX-327 Transponder	011-00490-00
		011-00490-10
Grimes	Flashtube Position Light	30-0515-3
		30-0515-5
		30-1172-1
		30-1172-3
		30-1172-5
ICOM	IC-A200 VHF Air Band Transceiver	IC-A200
ICOM	IC-A210 VHF Air Band Transceiver	IC-A210
McCoy	MAC-1700 Nav/Comm	82-01445-002
		82-01445-006
		82-01445-008
Narco	ADF-101 ADF Indicator	ADF 101
Narco	ADF-141 ADF Receiver	ADF-141

# CAPABILITIES LIST

Current as of: 11/01/2020

Narco	ADF-841 ADF Receiver	ADF-841
Narco	AK-350 Altitude Encoder (Testing)	AK-350
Narco	AR-850 Altitude Reporter (Alignment, Calibration, and Testing)	03753-0302
Narco	AR-850 L/C Altitude Reporter (Alignment, Calibration, and Testing)	03753-0300
Narco	AT-50 Transponder	AT-50
Narco	AT-50A Transponder	AT-50A
Narco	AT-150 Transponder	03606-0300C 03606-0302C
Narco	Com 10 Comm	Com 10
Narco	Com 10A Comm	Com 10A
Narco	Com 11 Comm	Com 11
Narco	Com 11A Comm	Com 11A
Narco	Com 11B Comm	Com 11B
Narco	Com 111B Comm	Com 111B
Narco	Com 120 Comm Transceiver	Com 120 Com 120/20
Narco	Com 810 Comm Transceiver	03114-0309 03114-0311
Narco	Com 811 Transceiver	03114-0303
Narco	CP-126 Audio Panel w/Marker Beacon Receiver	CP-126
Narco	CP-135 Audio Panel	CP-135
Narco	CP-135M Audio Panel & Marker Beacon Receiver	CP-135M
Narco	CP-136 Audio Panel w/Marker Beacon Indicator	03740-0302



# CAPABILITIES LIST

Current as of: 11/01/2020

Narco	CP-136M Audio Panel w/Marker Beacon Receiver	03740-0302
Narco	DME-40 DME	DME 40
Narco	DME-190 DME	DME 190
Narco	DME-195 DME	DME 195
Narco	DME-890 DME	03314-0300
Narco	ESCORT II NAV/COMM (Bench Test Only)	ESCORT II
Narco	ID-824 Indicator	03749-0300
Narco	ID-825 Indicator	03749-0301
Narco	IDME-891 DME/VOR/LOC/GS/Marker Beacon Ind	01424-0101
Narco	MK-12D NAV/COM	03118-0304 03118-0305 03118-0306 03118-0307
Narco	MK-12E NAV/COM	01442-0101 01442-0102
Narco	NAV-10 NAV Receiver	Nav-10
Narco	NAV-11 VOR/LOC Indicator / NAV Receiver	Nav-11
Narco	NAV-12 VOR/ILS Indicator / NAV Receiver	Nav-12
Narco	NAV-14 NAV Receiver	Nav-14
Narco	NAV-111 VOR/LOC Indicator/Receiver	Nav-111
Narco	NAV-112 VOR/LOC/GS Indicator/Receiver	Nav-112
Narco	NAV-121 VOR/LOC Indicator/Receiver	03723-0300 03723-0309
Narco	NAV-122 VOR/LOC/GS/MKR Indicator/Receiver	03723-0301 03723-0310

# CAPABILITIES LIST

Current as of: 11/01/2020

Narco	NAV-122A VOR/LOC/GS/MKR Indicator/Receiver	03723-0302 03723-0311
Narco	NAV-122D VOR/LOC/GS Indicator/Receiver (Bench Test Only)	03128-0300 03128-0301 03128-0302
Narco	NAV-124 VOR/LOC/GS/MKR System	03724-0302
Narco	NAV-124A VOR/LOC/MKR System	03724-0300
Narco	NAV-124R VOR/LOC Receiver	03724-0301
Narco	NAV-824 NAV Receiver	NAV-824
Narco	NAV-825 NAV Receiver	NAV-825
Narco	NCS-812 NAV/COMM	01442-0103
Narco	UGR-2 Glide Slope Receiver	UGR-2
Narco	UGR-2A Glide Slope Receiver	UGR-2A
Narco	UGR-3 Glide Slope Receiver	UGR-3
Narco	VOA-4 Omni/LOC Nav Conv	VOA-4
Narco	VOA-5 Omni/LOC Nav Conv w/GS Indicator	VOA-5
Narco	VOA-8 Omni/Localizer Converter	VOA-8
Narco	VOA-9 VOR ILS Course Deviation Indicator	VOA-9
Narco	VOA-40 Series Navigation Converter	VOA-40
Narco	VOA-50 Series Navigation Converter	VOA-50
Sigtronics	SPA-400 Intercom (Bench Test Only)	SPA-400 11-02791
Sperry	TP-114B Transponder	6097768-200
S-TEC	IND-650A ADF Indicator	690113-P
S-TEC	RCR-650A ADF Receiver	690108-P

# CAPABILITIES LIST

Current as of: 11/01/2020

Terra/Trimble	AT-3000 Altitude Encoder	0900-4099-01 1900-0259-10
Terra/Trimble	EPU 28-24 RM Emergency Power Unit	0900-1840-22
Terra/Trimble	TDF-100D ADF	0900-0406-00
Terra/Trimble	TMA-230 Audio Panel / Marker Beacon Receiver	TMA-230 0900-0402-00
Terra/Trimble	TMA-330D Audio Panel / Intercom	0900-0418-00 1900-0593-00
Terra/Trimble	TMA-340D Audio Panel / Intercom	1900-0595-00
Terra/Trimble	TMA-350D Audio Panel / Marker Beacon Receiver	0900-0409-00 1900-0592-00
Terra/Trimble	TN-200 NAV Receiver	1900-0200-01
Terra/Trimble	TN-200D NAV	0900-0404-X0 1900-0350-00 1900-0350-10
Terra/Trimble	TPX-720 Portable Handheld VHF Transceiver	0900-0720-00
Terra/Trimble	TRI NAV VOR/LOC/GS Indicator	0900-1100-00 0900-1100-11 1900-0579-00
Terra/Trimble	TRI NAV C VOR/LOC/GS Indicator	0900-1100-10 1900-0580-00
Terra/Trimble	TRT-250 Transponder	0900-0250-00 0900-0250-10 0900-0250-20
Terra/Trimble	TRT-250D Transponder	0900-0250-30 1900-0365-00
Terra/Trimble	TX-720 COMM Transceiver	0900-0725-03 0900-0725-11

# CAPABILITIES LIST

Current as of: 11/01/2020

Terra/Trimble	TX-760D COMM	0900-0405-00 0900-0405-10 1900-0361-00
Terra/Trimble	TXN-920 NAV/COMM Transceiver	0900-0727-00 0900-0727-10
Terra/Trimble	TXN-960 NAV/COMM	0900-0728-10 0900-0728-20 0900-0728-30
TKM/Michel	MBT-12 Marker Beacon Receiver	MBT-12
TKM/Michel	MBT-R Marker Beacon Receiver	MBT-R
TKM/Michel	MC-60 NAV Converter	MC-60
TKM/Michel	MX-11 COMM Transceiver	MX-11
TKM/Michel	MX-12 NAV/COMM Transceiver	MX-12
TKM/Michel	MX-170B NAV/COMM Transceiver	MX-170B
TKM/Michel	MX-170C NAV/COMM Transceiver	MX-170C
TKM/Michel	MX-300 NAV/COMM Transceiver	MX-300
TKM/Michel	MX-385 NAV/COMM Transceiver	MX-385
Wilcox	1014A ATC Transponder	097768-0101
Wilcox	1014B ATC Transponder	097768-0200

## Limited Instrument

<u>Manufacturer</u>	<u>Model</u>	<u>Part Number</u>
N/A	N/A	N/A